


庞伯特® 智能乒乓球台
CUBE 25 使用指南

Pongbot®Smart Ping-Pong Table CUBE 25 Operation Manual

型号 (Model): CUBE 25

版本 (Version): V1.0



PONGBOT
上海创屹科技有限公司
Shanghai Future Mind Co., Ltd.

如您在使用过程中，遇到任何问题，均可登录官网
或来电进行咨询！

If you encounter any problems during use, please call
customer service or consult the official website.

创屹官方网址 (Website): www.pong-bot.com

售后服务热线 (Customer Service): 400-190-6688



扫码观看安装视频
Scan and watch
Installation Instruction



关注创屹微信公众号
了解最新产品资讯
Scan and follow our
official Wechat account

安全信息 Safety Information

在使用和操作设备前，为确保设备性能最佳，并避免出现危险或非法情况，
请查阅并遵循所有的安全信息

To avoid danger and illegality, please carefully read and follow all of the below-
mentioned safety information prior to installation and utilization of the device

操作与安全 Safety Instructions

为了防止可能的身体疲劳，请勿长时间使用锻炼

• 请在温度 -10°C ~ 45°C 范围内使用本设备，并在此温度范围内存放设备及其配件。

当环境温度过高或过低时，可能会引起设备故障

• 请勿将设备暴露在高温或发热设备的周围，如取暖器、微波炉、烤箱或热水器等

• 使用设备时，电源插座应安装在设备附近并易于触及

• 当设备不使用时，请断开电源适配器与设备的连接并从电源插座上拔掉电源

• 使用未经认可或不兼容的电源适配器，可能引发火灾、爆炸、设备损坏或其他危险

• 只能使用设备制造商认可且与此型号设备配套的配件。如果使用其他类型的配件，

可能违反本国设备保修条款及相关规定，并可能导致安全事故。如需获取认可的

配件，请与创屹科技客户服务中心联系

• 使用非授权第三方软件升级设备固件和系统，可能存在设备无法使用或者泄露

您个人信息等安全风险。建议您使用官方 APP 进行升级

To avoid physical fatigue, please do not exercise long-termly

• Please use and store the device and its accessories under the environment of -10°C ~ 45°C.

When the temperature is too high or low, an error might occur

• Please do not expose device to surroundings of other high-temperature devices, including

heater, microwave, oven, water heater, etc.

• During use, the power outlet should be close to the device and within reach

• When not in use, please disconnect the power adapter from the device and remove the power plug

from the outlet

• Be aware that uncertified or incompatible power adapter might cause fire, explosion and other

potential danger

• Please only use accessories that are certified by the device manufacturer or corollary equipment

of the device. Any other type of accessories might result in violation of national warranty and

related regulations that could cause safety incidents. Please contact Pongbot's Customer Service

Center for certified accessories

• Use of uncertified, third-party software during firmware and system update might result in

dysfunctional device or leakage of personal information. To upgrade, use of official APP is highly

recommended

上海市浦东新区金锐路 199 号

No.199 Jinwan Rd., Pudong Shanghai

+86 4001906688

marketing@pong-bot.com

www.pong-bot.com

版权所有 © 上海创屹科技有限公司。保留一切权利。本指南仅供参考，不构成任何明示或暗示、产品或服务的不受限制。尺寸、重量等请以实物为准。

Copyright © Shanghai Pongbot Co., Ltd. All rights reserved. This guide is for reference only and does not constitute any kind of commitment. Products

(including but not limited to color, size, weight, etc.) shall prevail in kind.

目录 (Table of Contents)


1. 产品构成 (Product Info)

2. 安装指导 (Installation)

3. APP 使用 (APP Features)

产品构成 (Product Info)


1 智能球台 (Smart Ping-Pong Table)



- | | |
|---|--|
| 1 转换模块连接器接口
Transition Module Connector | 8 折铰 ×4
Hinge ×4 |
| 2 主控模块连接器接口
Control Module Connector | 9 可调节地脚 ×4
Adjustable Feet×4 |
| 3 电源适配器接口
Power Adapter | 10 T 型腿(含脚轮) ×4
T-joint Leg (including castors)×4 |
| 4 电源开关
Power Button | 11 T 型腿安装板金 ×8
T-joint Leg Installation Plates×8 |
| 5 指示灯
LED Indicators | 12 A-B 半台连接线
A-B Connection Cable |
| 6 开始 / 停止按键
Start/Stop Button | 13 球网及网架
Net |
| 7 静音 / 蓝牙配对按键
Mute/BLE Connection Button | |

2 传感器 (Sensor)

(各半台 4 个, 共 8 个)
4 sensors per half-table, total of 8



- | | |
|---|-------------------------------------|
| 3 插销 ×2
Securing Bolts×2
(各半台 1 个, 共 2 个)
1 bolts per half-table, total of 2 | 4 USB Type-C 电源线
Power Cable |
| 5 安装扳手 ×2
Wrench×2 | 6 T 型腿安装用小零件:
T-joint Leg Parts: |
| | 螺母 ×8
Nuts×8 |
| | 螺栓 ×8
Bolts×8 |
| | 垫片 ×16
Gaskets×16 |


安装指导 (Installation)

安装球桌时需注意安全，请 2 人配合进行安装
For your safety, this installation requires a minimum of two-people.

- 1 移除泡沫保护层，取出半球球台面，下架朝上，置于
包装纸箱或垫有软物的地面后，将插销拔出(见产品
构成 5)


Remove protection foam and take out half-table. Its legs should
be facing up as shown below. Pull out the securing bolt (Product
Info 3). To avoid scratches, make sure it's placed on top of the
packaging box.

- 2 在确认插销已拔出后，向上提拉球台下架至与球桌
桌面垂直状态。**注意请勿提拉折铰（易变形）！**
Lift up all legs (note that they should be perpendicular
to table surface). Please avoid lifting the hinges for
they might deform.




- 3 将 T 型腿(见产品构成 10)与球台下架对齐，前后
卡紧安装板金(见产品构成 11)

Insert T-joint leg (Product Info 10), and place the installation
plates (Product Info 11) on both sides of the leg (front and
back) to secure.




- 4 使用垫片和螺栓、螺母(见产品构成 6)连接安装
板金，并使用安装扳手(见产品构成 5)将其拧紧
固定于下架




- 5 按下折铰(见产品构成 8)至弯曲状，将球台往上翻起，
移动到适合摆放的位置，再将折铰拉直

Bend the hinge (Product Info 8), lift and flip over the table. Once
the table is placed at a desired position, straighten the hinge.




- 6 重复步骤 1 至 5 完成另一半球台的拼装
Repeat step 1 to 5 to complete installing the other half-table

- 7 将已安装好的对半球台拼凑在一起(注意方向)
Place the installed two half-tables together



- 8 旋转球台可调节地脚(见产品构成 9)，调节球台 4 个
边角的高度，保持球台面离地 76cm，按下 4 个
T 型腿底部脚轮刹，旋转脚轮，调至适当的高度后，
将脚轮固定

Rotate to adjust the height of the four adjustable feet (Product
Info 9). The ideal distance between table surface and ground
is 76cm. Rotate to adjust the castors from the T-joint legs,
press down and secure all of the castors once an ideal height
is reached.



操作与安全 Safety Instructions

为了防止可能的身体疲劳，请勿长时间使用锻炼

• 请在温度 -10°C ~ 45°C 范围内使用本设备，并在此温度范围内存放设备及其配件。

当环境温度过高或过低时，可能会引起设备故障

• 请勿将设备暴露在高温或发热设备的周围，如取暖器、微波炉、烤箱或热水器等

• 使用设备时，电源插座应安装在设备附近并易于触及

• 当设备不使用时，请断开电源适配器与设备的连接并从电源插座上拔掉电源

• 使用未经认可或不兼容的电源适配器，可能引发火灾、爆炸、设备损坏或其他危险

• 只能使用设备制造商认可且与此型号设备配套的配件。如果使用其他类型的配件，

可能违反本国设备保修条款及相关规定，并可能导致安全事故。如需获取认可的

配件，请与创屹科技客户服务中心联系

• 使用非授权第三方软件升级设备固件和系统，可能存在设备无法使用或者泄露

您个人信息等安全风险。建议您使用官方 APP 进行升级

To avoid physical fatigue, please do not exercise long-termly

• Please use and store the device and its accessories under the environment of -10°C ~ 45°C.

When the temperature is too high or low, an error might occur

• Please do not expose device to surroundings of other high-temperature devices, including

heater, microwave, oven, water heater, etc.

• During use, the power outlet should be close to the device and within reach

• When not in use, please disconnect the power adapter from the device and remove the power plug

from the outlet

• Be aware that uncertified or incompatible power adapter might cause fire, explosion and other

potential danger

• Please only use accessories that are certified by the device manufacturer or corollary equipment

of the device. Any other type of accessories might result in violation of national warranty and

related regulations that could cause safety incidents. Please contact Pongbot's Customer Service

Center for certified accessories

• Use of uncertified, third-party software during firmware and system update might result in

dysfunctional device or leakage of personal information. To upgrade, use of official APP is highly

recommended

上海市浦东新区金锐路 199 号

No.199 Jinwan Rd., Pudong Shanghai

+86 4001906688

marketing@pong-bot.com

www.pong-bot.com

版权所有 © 上海创屹科技有限公司。保留一切权利。本指南仅供参考，不构成任何明示或暗示、产品或服务的不受限制。尺寸、重量等请以实物为准。

Copyright © Shanghai Pongbot Co., Ltd. All rights reserved. This guide is for reference only and does not constitute any kind of commitment. Products

(including but not limited to color, size, weight, etc.) shall prevail in kind.

APP 使用 (APP Features)

(Currently APP and related services are only available in China)

- 1 使用**庞伯特 APP** 探索更多功能，请通过以下渠道下载 APP
Download the Pongbot APP to explore more product features,
please download via:

- 扫码下载 (Scan QR code)
- 官网下载 (Official website: www.pong-bot.com)
- 各大应用市场搜索“PONGBOT”或“庞伯特”下载
(Search "Pongbot" at APP stores)



- 2 请在注册账号后登录，进入 APP
Please register an account and log in.



- | | | |
|--|--|--|
| 2.1
于“设备”列表页点击
“+”添加设备
Click “+” to add
new device | 2.2
智能乒乓球台
Select Smart
Ping-Pong Table | 2.3
选中您的设备后点击
“蓝牙配对”
Select your device and
click “BLE Connection” |
|--|--|--|

使用 APP 可探索更多功能

Download APP to explore more product features.

(Currently APP and related services are only available in China)

Warranty Card

Pongbot®Smart Ping-Pong Table

Customer Info

Name: _____ Address: _____

Phone: _____ Postal Code: _____

E-Mail: _____

Product Info

Model: _____ SN: _____

Origin: _____ Service: 400-190-6688

Retailer Info

Name: _____ Address: _____

Phone: _____ Postal Code: _____

Invoice #: _____ Date of Sale: _____

Retailer Stamp: _____

Notice:

• Pongbot®Smart Ping-Pong Table strictly follows and executes national warranty
regulations. Pongbot values and respects consumers' rights, we solemnly promise to
provide post-sales services, maintenance, exchanges and returns under national regulations.

• Below-mentioned situations are not included in warranty:

- Human factors and abnormalities that cause damage to the device (ex. harmful power source,
foreign matter enters the device, poor transportation by customers, etc.)
- Disassemble and maintenance behavior by non-appointed personnel that causes damage
and regulations
- Performance index and technical parameters meet the standards of product design
- Forced device operation when parts have been damaged or aged
- Use of non-original accessories (not manufactured by Pongbot) that causes error or damage
- Unavoidable factors that cause device damage, including natural disasters, such as
earthquake, flood, fire, etc.
- Products that exceed warranty periods

三包凭证

庞伯特®智能乒乓球台

用户信息

姓名: _____ 地址: _____

电话: _____ 邮政编码: _____

邮箱: _____

产品信息

型号: _____ SN: _____

产地: _____ 服务热线: 400-190-6688

销售商信息

姓名: _____ 地址: _____

电话: _____ 邮政编码: _____

发货票号: _____ 销售日期: _____

销售商印章: _____

备注:

- 庞伯特®智能乒乓球台严格执行国家三包法，遵守行业准则，并充分尊重
消费者权益，为消费者提供全方位服务保障和郑重承诺，对国家规定或者
与消费者约定包修、包换、包退的商品，创屹科技承诺负责修理、更换或者退货
- 以下情况不属于三包范围：
- 人为因素和非正常原因(不良的电源环境、异物进入设备、客户不良运输等)
造成设备的损坏
 - 非创屹科技指定服务人员所拆解、维修等行为造成设备的损坏
 - 性能指标或技术参数达到产品设计及说明标准的
 - 在零部件发生老化或损坏的情况下强制运行造成设备的损坏
 - 使用非创屹科技原厂配件造成设备的故障或损坏
 - 不可抗因素造成设备损坏，如地震、洪水、火灾等自然灾害
 - 已超过保修期的产品